



Polaris Hose Connector Replacement Instructions

1. Collapse the hose with your fingers and remove the hose connector that is being replaced.
2. With the end of the hose still collapsed, slide the new hose connector onto the hose. Make sure only the first corrugation of hose is inside the lip of the connector.
3. Stick your finger inside the hose and pop it back into shape.

